





Koppla in konferenskameran MeetUp till Zoom

1. Börja med att koppla in den uppmärkta USB-kabeln i din dator.
2. Starta Zoom och klicka på kugghjulet i det övre högra hörnet.


3. Klicka på Video till vänster och välj Logitech MeetUp. Justera videoinställningarna för widescreen och aktivera HD om nödvändigt.



4. Klicka på Audio till vänster och välj Logitech MeetUp som både högtalare och mikrofon. Testa genom att klicka på knapparna.



5. Använd fjärrkontrollen på katedern för att justera kamerans zoomnivå och riktning. Hemknappen på fjärrkontrollen återställer kameran till dess standardposition.




- | | |
|-----------------------|--|
| 1. Microphone mute | 7. Camera pan/tilt |
| 2. Call answer | 8. Camera home |
| 3. Call end | 9. Camera preset |
| 4. Bluetooth® pairing | * Please note that not all applications support call answer and end buttons. |
| 5. Volume up/down | |
| 6. Zoom in/out | |




Connect the MeetUp conference camera to Zoom

1. Start by plugging the marked USB-cable into your computer.
2. Start Zoom and click on the gear wheel in the upper right corner.


3. Click on "Video" on the left and select Logitech MeetUp. Adjust the video settings for widescreen and activate HD if necessary.



4. Click on "Audio" on the left and select Logitech MeetUp as both speaker and microphone. Test the sound by clicking the buttons.



5. Use the remote control on the teacher desk to adjust the camera position and zoom level. The "home" button on the remote control resets the camera to its default position.



- | | |
|-----------------------|--|
| 1. Microphone mute | 7. Camera pan/tilt |
| 2. Call answer | 8. Camera home |
| 3. Call end | 9. Camera preset |
| 4. Bluetooth® pairing | * Please note that not all applications support call answer and end buttons. |
| 5. Volume up/down | |
| 6. Zoom in/out | |